

# 1986-1991 Rear Camber Adjuster Kits



PT.NO. AWR-7420

---

NOTE - **Do not** use these individual camber kits if you are running a solid delrin outer control arm bushing. Factory rubber bushing or aftermarket urethane bushings are acceptable!

This kit includes:

- 1 left hand independent camber adjuster
- 1 right hand independent camber adjuster
  - **IMPORTANT:** These items replace the rear control arm inside dog bone. They are stamped left and right and cannot be switched.

Tip: Use anti-seize or grease on all hardware during installation of this product. These items are designed to use the factory hardware.

INSTALLATION: With car safely on jack stands or hoist, remove original factory dog bones in the inner control arm suspension point. Install camber adjusters with the cap head of the bolt positioned to the ground upon installation. Install link into sub frame. Then, install into control arm. Tighten hardware. Do not loosen the **middle** jamb nut!

FOR THE ADJUSTMENT: Loosen top jamb nut and turn the cap head Allen counter clockwise to increase camber and clockwise to reduce camber. Be sure to tighten all hardware after installation and setting of camber.

